

PRACTICAL: 2

Using Forensic Tool: Autopsy.

Aim

To demonstrate the recovery of deleted files using the Autopsy Digital Forensics Tool by creating a forensic image with FTK Imager, deleting selected files, and analyzing the image in Autopsy.

System Prerequisites

- Computer system with Windows Operating System
- FTK Imager installed on the system
- Autopsy installed on the system
- Minimum 4 GB RAM (8 GB recommended)
- Sufficient free disk space to store image and case files
- Administrator privileges on the system

Tools Required

- FTK Imager
- Autopsy Digital Forensics Tool
- External storage device or test folder
- Sample test files (documents, images, text files, etc.)

About Autopsy

Autopsy is an open-source digital forensics platform used for analyzing disk images and recovering digital evidence. It provides a graphical interface for The Sleuth Kit and allows investigators to examine file systems, recover deleted files, analyze metadata, and generate forensic reports. Autopsy is widely used in academic laboratories and professional investigations for post-acquisition forensic analysis.

Procedure (Attach Screenshots for Each Step)

Step 1: Create Test Files

1. Create a folder on the system (e.g., Test_Evidence).
2. Add five test files of different types (e.g., .txt, .pdf, .jpg, .docx, .png).

Step 2: Create Forensic Image Using FTK Imager

3. Open FTK Imager with administrator privileges.
4. Click File → Create Disk Image.
5. Select Contents of a Folder and choose the *Test_Evidence* folder.



6. Select the image format (RAW or E01).
7. Enter case details and choose a destination path.
8. Enable hash calculation and start imaging.
9. Wait for the image creation to complete and verify hash values.

Step 3: Delete Test Files

10. Go to the original *Test_Evidence* folder.
11. Delete all five test files.
12. Empty the Recycle Bin to ensure permanent deletion.

Step 4: Analyze and Recover Files Using Autopsy

13. Launch Autopsy and create a New Case.
14. Enter case name, examiner details, and select case directory.
15. Add data source → Disk Image or VM File.
16. Browse and select the forensic image created using FTK Imager.
17. Configure ingest modules (file system, deleted file recovery, hash lookup).
18. Start the analysis process.
19. Navigate to Deleted Files section.
20. Identify and recover the deleted test files.
21. Export recovered files if required.



Select File

Evidence Source Selection

Please enter the source path:

C:\Users\bca\Downloads\ntfs1-gen0.E01

Browse...

< Back

Finish

Cancel

Help

Exterro FTK Imager 4.7.3.81

File View Mode Help



File List



Name	Type	Size	Date Modified
------	------	------	---------------

00000000	EB 52 90 4E 54 46 53 20-20 20 20 00 02 01 00 00	eR-NTFS	
00000010	00 00 00 00 00 F8 00 00-3F 00 FF 00 00 00 00 00s...?y.....	
00000020	00 00 00 00 80 00 00 00-FF 64 0F 00 00 00 00 00yd.....	
00000030	AA 21 05 00 00 00 00 00-7F B2 07 00 00 00 00 00	*.....f.....	
00000040	02 00 00 00 08 00 00 00-C7 CC 48 50 E8 48 50 DAçIHPEHPÜ	
00000050	00 00 00 00 FA 33 C0 8E-D0 BC 00 7C FB B8 C0 07ú3Ä-D%-jü,Ä-	
00000060	8E D8 E8 16 00 B8 00 0D-8E C0 33 DB C6 06 0E 00	..èè.....ÄSÜE...	
00000070	10 E8 53 00 68 00 0D 68-6A 02 CB 8A 16 24 00 B4	..èS-h-hj-È-ç-f	
00000080	08 CD 13 73 05 B9 FF FF-8A F1 66 0F B6 C6 40 66	..i-s-'yy-ñf-ñE8f	
00000090	0F B6 D1 80 E2 3F F7 E2-86 CD C0 ED 06 41 66 0F	..gü-â?+â-îâi-Äf-	
000000a0	B7 C9 66 F7 E1 66 A3 20-00 C3 B4 41 BB AA 55 8A	..Èf+âfâ-Ä'A»*U-	
000000b0	16 24 00 CD 13 72 0F 81-FB 55 AA 75 09 F6 C1 01	..ç-I-r-üU*u-öÄ-	
000000c0	74 04 FE 06 14 00 C3 66-60 1E 06 66 A1 10 00 66	..t-p-..Äf...f...f	
000000d0	03 06 1C 00 66 3B 06 20-00 0F 82 3A 00 1E 66 6A	...f;...:...fj	
000000e0	00 66 50 06 53 66 68 10-00 01 00 80 3E 14 00 00	..fP-Sfh...>...	
000000f0	0F 85 0C 00 E8 B3 FF 80-3E 14 00 00 0F 84 61 00	...è'y>.....a-	
00000100	B4 42 8A 16 24 00 16 1F-8B F4 CD 13 66 58 5B 07	..B-ç....öf-fX[
00000110	66 58 66 58 1F EB 2D 66-33 D2 66 0F B7 0E 18 00	..EXEX-a-f30f.....	
00000120	66 F7 F1 FE C2 8A CA 66-8B D0 66 C1 EA 10 F7 36	f+RpÄ-Èf-DrÄe-+6	
00000130	1A 00 86 D6 8A 16 24 00-8A E8 C0 E4 06 0A CC B8	...ö-ç...èÄÄ-ï,	
00000140	01 02 CD 13 0F 82 19 00-8C C0 05 20 00 8E C0 66	...ï.....Ä-Äf	
00000150	FF 06 10 00 FF 0E 0E 00-0F 85 6F FF 07 1F 66 61	g...y.....oy-Äa	
00000160	C3 A0 F8 01 E8 09 00 A0-FB 01 E8 03 00 FB EB FE	Ä s-è...ü-è-üep	
00000170	B4 01 8B F0 AC 3C 00 74-09 B4 0E BB 07 00 CD 10	...è-<-t'f>...I-	
00000180	EB F2 C3 0D 0A 41 20 64-69 73 6B 20 72 65 61 64	èöÄ...A disk read	
00000190	20 65 72 72 6F 72 20 6F-63 63 75 72 72 65 64 00	error occurred-	
000001a0	0D 0A 4E 54 4C 44 52 20-69 73 20 6D 69 73 73 69	..NTLDR is missi-	
000001b0	6E 67 00 0D 0A 4E 54 4C-44 52 20 69 73 20 63 6F	ng...NTLDR is co	
000001c0	6D 70 72 65 73 73 65 64-00 0D 0A 50 72 65 73 73	mpressed...Press	
000001d0	20 43 74 72 6C 2B 41 6C-74 2B 44 65 6C 20 74 6F	Ctrl+Alt+Del to	
000001e0	20 72 65 73 74 61 72 74-0D 0A 00 00 00 00 00 00	restart.....	
000001f0	00 00 00 00 00 00 00 00-83 A0 B3 C9 00 00 55 AA'E...U*	
00000200	05 00 4E 00 54 00 4C 00-44 00 52 00 04 00 24 00	..N-T-L-D-R-ç-	
00000210	49 00 33 00 30 00 00 E0-00 00 00 30 00 00 00 00	I-3-0-Ä-0-0-0-0	
00000220	00 00 00 00 00 00 00 00-00 00 00 00 00 00 00	
00000230	00 00 00 00 00 00 00 00-00 00 00 00 00 00 00	
00000240	00 00 00 00 00 00 00 00-00 00 00 00 00 00 00	
00000250	00 00 00 00 00 00 EB 12-90 90 00 00 00 00 00è.....	
00000260	00 00 00 00 00 00 00 00-00 00 8C C8 8E D8 C1 E0È-öÄÄ	
00000270	04 FA 8B E0 FB E8 03 FE-66 0F B7 06 0B 00 66 0F	..ü-äüè-pf...f-	
00000280	B6 1E 0D 00 66 F7 E3 66-A3 4E 02 66 8B 0E 40 00	q...f+âfâN-f-0-	
00000290	80 F9 00 0F 8F 0E 00 F6-D9 66 B8 01 00 00 00 66	..ü-ü-öüf...f	
000002a0	D3 E0 EB 08 90 66 A1 4E-02 66 F7 E1 66 A3 52 02	öÄè-ç;N-f+âfâR-	
000002b0	66 0F B7 1E 0B 00 66 33-D2 66 F7 F3 66 A3 56 02	f-...f30f+öfâV-	

Cursor pos = 336; log sec = 0

For User Guide, press F1





1 2 3 4

Restore Session x Create A New Case x +

localhost:9999/autopsy?mod=0&view=1

Kali Linux Kali Tools Kali Docs Kali Forums Kali NetHunter Exploit-DB Google Hacking DB OffSec

CREATE A NEW CASE

1. **Case Name:** The name of this investigation. It can contain only letters, numbers, and symbols.

001

2. **Description:** An optional, one line description of this case.

data recovery

3. **Investigator Names:** The optional names (with no spaces) of the investigators for this case.

a.	nirav pathar	b.	
c.		d.	
e.		f.	
g.		h.	
i.		j.	

NEW CASE CANCEL HELP

1 2 3 4

Restore Session x Create A New Case x Screenshot_2025-12-30_00_ x +

localhost:9999/autopsy?mod=0&view=1

Kali Linux Kali Tools Kali Docs Kali Forums Kali NetHunter Exploit-DB Google Hacking DB OffSec

CREATE A NEW CASE

1. **Case Name:** The name of this investigation. It can contain only letters, numbers, and symbols.

001



2. **Description:** An optional, one line description of this case.



data recovery



3. **Investigator Names:** The optional names (with no spaces) of the investigators for this case.



a.	rudra patel	b.	
c.		d.	
e.		f.	
g.		h.	
i.		j.	



NEW CASE CANCEL HELP















Observation

- Forensic image successfully loaded into Autopsy
- Deleted files were identified and recovered
- File metadata and timestamps were visible

Conclusion

The experiment successfully demonstrated the recovery of deleted files using Autopsy. By creating a forensic image with FTK Imager before deletion, evidence integrity was preserved. Autopsy effectively analyzed the image and recovered deleted files, proving its usefulness in digital forensic investigations.

