

## **PRACTICAL: 1**

**Forensic imaging and analysis tool designed to acquire, create forensic images, and perform detailed analysis using FTK imager tool.**

**Aim: To create a forensically sound image file of a storage device using FTK Imager while ensuring data integrity for digital forensic investigation.**

### **System Prerequisites**

- Computer system with **Windows Operating System**
- **FTK Imager** installed on the system
- Minimum **4 GB RAM** (8 GB recommended)
- Sufficient **free disk space** to store the forensic image file
- **Administrator privileges** on the system

### **Tools Required**

- FTK Imager
- External storage device (to store the image file)

### **About FTK (Forensic Toolkit)**


FTK (Forensic Toolkit) is a comprehensive digital forensic software developed by AccessData. It is widely used by forensic investigators to acquire, analyze, and report digital evidence from various storage media. FTK supports in-depth analysis of file systems, deleted files, system artifacts, and metadata while ensuring evidence integrity.

FTK works closely with FTK Imager, which is used for forensic acquisition. The acquired image files are then processed and analyzed in FTK for investigation purposes. The tool provides advanced features such as keyword searching, data carving, registry analysis, email analysis, and bookmarking of evidence, making it suitable for professional and academic forensic investigations.

FTK is commonly used in cyber crime investigations, incident response, corporate investigations, and academic digital forensics laboratories.

**Procedure: (ATTACH SCREENSHOTS ALONG WITH EACH STEP)**

1. Open FTK Imager with administrator privileges.
2. Click on File → Create Disk Image.
3. Select the source type (Physical Drive / Logical Drive / Image File / Folder contents).
4. Choose the required drive or partition and click Next.
5. Select the image format such as RAW (dd) or E01.
6. Enter case details including case number, evidence number, examiner name, and description.
7. Select the destination path to save the image file.
8. Configure image fragmentation size if required.
9. Enable hash calculation (MD5/SHA1/SHA256).
10. Click Start to begin the imaging process.
11. Wait until the image acquisition is completed.
12. Verify that the generated hash values match.



Select Source

Please Select the Source Evidence Type

☐ Physical Drive

☐ Logical Drive

☒ Image File

☐ Contents of a Folder  
(logical file-level analysis only; excludes deleted, unallocated, etc.)

< Back

Next >

Cancel

Help

Select File

Evidence Source Selection

Please enter the source path:

C:\Users\bca\Downloads\ntfs1-gen0.E01

Browse...

< Back

Finish


Cancel

Help

Name	Type	Size	Date Modified
------	------	------	---------------

For User Guide, press F1

000000160	C3	A0	F8	01	E8	09	00	A0-F8	01	E8	03	00	FB	EB
000000170	B4	01	8B	F0	AC	3C	00	74-09	B4	0E	BB	07	00	CD
000000180	EB	F2	C3	0D	0A	41	20	64-69	73	6B	20	72	65	61
000000190	20	65	72	72	6F	72	20	6F-63	63	75	72	72	65	64



#### Observation:

- Forensic image file was successfully created
- Hash values before and after imaging were identical
- Data integrity was preserved

#### Conclusion:

FTK Imager was successfully used to create a forensic image file of a storage device. The matching hash values confirm the integrity and authenticity of the acquired evidence, making it suitable for further forensic analysis.